




HP Compaq C700 Key Replacement

This guide will show how to remove a key from the keyboard of a HP Compaq C700 laptop.

Written By: Taylor Johansen



INTRODUCTION

This guide details the process for removing an individual key to gain access underneath the key.



TOOLS:

- [iFixit Opening Tools](#) (1)
-

Step 1 — Key



- ⚠ It is advised to work on the device only when it is powered off so as to avoid electrocution risks.
- Turn off computer by pushing and holding on the power button located above the keyboard.

Step 2



- Position the opening tool under the edge of the key.
- Gently pry up one side of the key until the key pops out of place.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-25 01:57:41 AM.